


Bålpanne Ask

Art.nr 420280



Del	Art.nr	Navn
A	420281	Bålpanne Ask - Ben for bålfat (A) – Legs for grill bowl
B1	420258	Bålpanne Ask - midtre del ben stativ (B1) – Mid leg
B2	420259	Bålpanne Ask - øvre ben stativ med pigger (B2) - Upper leg with peg
B3	420260	Bålpanne Ask - Ben nedre del stativ (B3) – Lower leg
C	420285	Bålpanne Ask - rist m/vaier (C) - Grate
D	420286	Bålpanne Ask - Bålfat (D) – Grill bowl
E	420257	Bålpanne Ask - Toppdel (E) – Top
F	420288	Bålpanne Ask - vaier m/ kroker + trinse (F) – Wire with hooks
G	420307	Bålpanne Ask - Toppspiss (G)
K	420290	Bålpanne Ask - Gnistfanger (K) – Spark arrester
S1/S2/S6	420291	Bålpanne Ask - skruepose (komplett) - Screwbag

SUNWIND
URNORSK PÅ GRILLEN